

WARNING

Always obey all applicable safety rules.

Be sure all power to the conveyor has been disconnected and controls are locked out.

Step 1: Clean Installation Area

Remove debris from the application area to ensure a clean and secure magnetic bonding surface.

Step 2: Apply MagnaPlug pad

Put one half of the MagnaPlug magnets beside the worn area. Then place the wear pad over the worn area.

Step 3: Place MagnaPlug over pad

Stretch the free side of the MagnaPlug over the pad and attach it in position.



Step 4: Add Power Screw

Install the Power Screw to further tighten the wear pad against the hole.



Removal

To change the wear pad or remove the patch for repairs, insert a pry bar or other thin metal tool under the patch and lift.